


# AIRMASTER



|   | DK                               | NO                                | SV                                        | DE                           | NL                                        | FR                                            |
|---|----------------------------------|-----------------------------------|-------------------------------------------|------------------------------|-------------------------------------------|-----------------------------------------------|
| 1 | Afkast                           | Avkast                            | Avluft                                    | Fortluft                     | Afvoer                                    | Air rejeté                                    |
| 2 | Indtag                           | Inntak                            | Intag                                     | Außenluft                    | Toevoer                                   | Air extérieur                                 |
| 3 | Indblæsning                      | Tilluft                           | Tilluft                                   | Zuluft                       | Inblaas                                   | Air soufflé                                   |
| 4 | Udsugning                        | Avtrekk                           | Frånluft                                  | Abluft                       | Afzuiging                                 | Air repris                                    |
| 5 | Væggramme/Loftramme              | Veggramme/Takramme                | Väggram/Takram                            | Wandrahmen/Deckenrahmen      | Muurframe/Plafond frame                   | Cadre à fixation mural/Console de plafonnière |
| 6 | Kondens afløb                    | Kondensavløp                      | Kondensavlopp                             | Kondensatablauf              | Condensafvoer                             | Évacuation condensats                         |
| 7 | El-tilslutning                   | El-tilkobling                     | Elektrisk anslutning                      | Elektrischer Anschluss       | Elektrische aansluitingen                 | Raccordement électrique                       |
| 8 | Ophængssæt                       | Opphengssett                      | Takbeslag                                 | Deckenmontagesatz            | Plafondbevestigingen                      | Support de plafond                            |
| 9 | Vandeftervarme flade forbindelse | Vannettervarmebatteri forbindelse | Vattenburet eftervarmebatteri förbindelse | Wasserheiz-registeranschluss | Naverwarmingsbatterij op water verbinding | Batterie à eau chaude connexion               |

## AIRMASTER

Airmaster A/S  
Industrivej 59  
9600 Aars  
Danmark

Tel.: +45 98 62 48 22  
info@airmaster.dk  
www.airmaster.dk

Airmaster Belgique  
Santvoortbeeklaan 23B  
2100 Deurne  
Belgique

Tel.: +32 (0) 4 70 11 26 33  
info@airmaster.be  
www.airmaster-as.com/fr

Airmaster B.V.  
Lage Mosten 49  
4822 NK Breda  
Nederland

Tel.: +31 10 307 06 25  
info@airmaster-bv.nl  
www.airmaster-as.com/nl



Helios Ventilateurs  
Le Carré des Aviateurs  
157 av. Charles Floquet  
93155 Le Blanc Mesnil Cedex  
France

Tél. +33 1 48 65 75 61  
Fax. +33 1 48 67 28 53  
info@helios-fr.com  
www.helios-fr.com



SAV Systems  
Scandia House, Boundary Road  
Woking, Surrey  
GU21 5BX  
United Kingdom

Tel: +44 1483 771910  
info@sav-systems.com  
www.sav-systems.com



J. Pichler Gesellschaft m.b.H.  
Karlweg 5  
9021 Klagenfurt am Wörthersee  
Österreich

Tel.: +43 (0)463 32 7 69  
Fax: +43 (0)463 37 5 48  
office@pichlerluft.at  
www.pichlerluft.at



WESCO AG  
Tägerhardstrasse 110  
5430 Wettingen  
Schweiz

Tel. +41 56 438 12 12  
Fax. +41 56 438 12 10  
airmaster@wesco.ch  
www.wesco.ch